


Without AEC  
Without AEC  
Without AEC  
Without AEC  
Without AEC

# Without AEC

# With Rane's AEC

AEC: Acoustic Echo Canceling





HAL Note 109 • [rane.com/hal](http://rane.com/hal)  
Call Us: 425-355-6000 • Mukilteo Washington USA




# Walls move, and the AEC reference automatically routes.

HAL's Conference Room Combine block handles changing mic and loudspeaker I/O automatically – even when there's local voice lift. There's no need to manually configure behaviors and routing as head table locations move or rotate, and / or when rooms combine.



## Works with the Rane EXP7x AEC Expander in HAL1x Systems



HAL Note 109 • [rane.com/hal](http://rane.com/hal)  
Call Us: 425-355-6000 • Mukilteo Washington USA

